

2" FAUX WOOD BLINDS INFORMATION SHEET

CARE & CLEANING

ALL OF OUR PRODUCTS ARE DESIGNED TO REQUIRE **MINIMAL CARE AND MAINTENANCE**, BUT WE DO RECOMMEND THAT YOU **DUST WITH A FEATHER DUSTER**. THIS WILL MAINTAIN A LIKE-NEW APPEARANCE.

FOR SOME VINYL FABRICS OR VERTICAL VANES, YOU CAN WIPE OFF ANY DIRT OR STAINS WITH A **DAMP CLOTH** WHEN NECESSARY.

YOU MAY ALSO USE **COMPRESSED AIR** FROM A CAN OR **BRUSH ATTACHMENT** FROM YOUR HOUSEHOLD VACUUM TO DUST OFF SELECTED PRODUCTS.

WE DO NOT RECOMMEND THE USE OF ANY DETERGENTS AS THIS MAY DAMAGE THE PRODUCT.



- CORDLESS OPERATION
- WAND TILT
- SMOOTH SATIN FINISH
- SNOW WHITE COLOR
- 3" CROWN VALANCE
- 1 YEAR WARRANTY

ECONOMICAL, DURABLE, AND EASY TO MAINTAIN.

MADE OF THE **HIGHEST QUALITY SYNTHETIC MATERIALS**, OUR **2" FAUX WOOD BLINDS** ARE **100% UV AND ANTI-STATIC CONTROLLED** SO THEY WON'T YELLOW OR COLLECT EXCESS DUST.

TO TILT

Twist the wand.

TO RAISE

First, tilt blinds to the fully open position. Then to raise the blind, use both hands on each side of the bottom rail to gently lift it up.

TO LOWER

First, tilt blinds to the fully open position. Then to lower the blind, use both hands on each side of the bottom rail to gently pull it down.

TROUBLESHOOTING

If the blinds are moved to an uneven position or don't sit flat on the window sill, use both hands on the each side of the bottom rail to slowly raise and lower blinds until they level out.

EASY OPERATION

